

WARING COMMERCIAL

Europe TORq Blender

with Electronic Keypad & Timer

TBB160E




503481

Blade Assembly



024271

O Ring




035307

Bearing Holder Nut

035465









Blending Assembly

(with O ring and bearing holder nut)





035872

Control Panel Overlay




503482

Container with Blending Assembly



Illustration#	Part#	Description
1	028769-E	Eastman Jar Lid Cover
2	035238-V	Vinyl Jar Lid
3	035465	Blending Assembly (with O ring and bearing holder nut)
4	035239	48 oz. Stackable Container ONLY
5	035885 035091	Jar Pad (<i>changed after 7/18/2018</i>) Jar Pad (use 035885)
6	035085	Hole Plug (4 required)
7	034275	Sems (4 required)
8	034273	B Gasket (4 required)
9	037032 035251	Drive Copling (<i>on units after 11/15/2019</i>) Drive Coupling
9a	037036	Coupling Washer (<i>on units after 11/15/2019</i>)
10	503460-160-E	Top Housing Assembly
11	035237	Control Housing Back Bezel
12	035090	Screw (4 required)
13	035253	LED Lens
14	035165	TBB160 230 volt Control Panel
15	034900	PCB Cushion (4 required <i>on units after 8/9/2018</i>) (2 required)
16	013604	Washer (4 required <i>on units after 8/9/2018</i>) (2 required)
17	034904	Rubber Grommet (4 required)
18	034902	Sems (4 required)
19	035894	Control Board Bracket
20	034272	A Gasket (4 required)
21	034274	Screw (4 required)
22	035816 035475	Chiaphua Motor No Sensor (<i>on units after 6/20/2018</i>) ECM Motor
23	503483	Motor Housing with Dampeners
24	012409	Small Crimp Connectors (3 required)
	019123	Large Crimp Connector (2 required)
25	013731	Cable Ties (8 required)
26	017948	Cord
27	033619	Strain Relief

Illustration#	Part#	Description
28	503480 035079	Bottom Housing Assembly with Feet Bottom Housing
29	034274	Screw (4 required)
30	035088	Foot (4 required)



Date Code Location
 YY|MM|DD
 year|year|month|month|day|day

